

Fracture Characterization and SEM Examination of CC6 Mixes

PENNSSTATE



Contributions to one CC6 Objective

Investigate the relative effect of concrete strength on test item performance:

- Will concrete that is “too strong” perform poorly?
- Is the current flexural strength limitation in AC 150/5320-6E justified by objective full-scale test data?

Material (relative target flexural strength)	MRS1 (low)	MRS2 (medium)	MRS3 (high)
Target Strength (modulus of rupture), psi	500	750	1000
Harmony No. 57 Stone, Round, lbs	1550		
No. 57 Coarse Aggregate, lbs		1475	1535
No. 8 Intermediate Coarse Aggregate, lbs		490	535
Harmony Concrete Sand, lbs	1414		
Concrete Sand, lbs		1225	1070
Water, lbs	325	230	236
Type 1 Portland Cement, lbs	460	500	680
Air, %	6.5	7	4.5
Slump, in.	6	5.5	3.5
SIKAair, oz.	4.5	5	4.5
w/c Ratio	0.71	0.46	0.35

1N	2N	3N	4N*	5N	6N
20N	21N	22N	23N	24N	25N
1S	2S	3S	4S	5S	6S
20S	21S	22S	23S	24S	25S

MRS1: Low-Strength Mix

7N	8N	9N	10N	11N	12N	13N
26N	27N	28N	29N	30N	31N	32N
7S	8S	9S	10S	11S	12S	13S
26S	27S	28S	29S	30S	31S	32S

MRS2: Med-Strength Mix

14N	15N	16N	17N	18N	19N
33N	34N	35N	36N	37N	38N
14S	15S	16S	17S	18S	19S
33S	34S	35S*	36S	37S	38S


MRS3: High-Strength Mix

Flexural Beam Fatigue Testing

- Initial testing of a limited number of cast beams at Penn State (MRS1)
- Remainder of fatigue testing conducted at NAPTF lab
- Beams sawn after full-scale loading completed

Fatigue Characterization

Structural Condition Index (SCI)




- **Could material properties in addition to flexural strength improve the correlation to fatigue performance?**
- **Fracture energy has been suggested as showing promise for correlation to fatigue performance.**


Test Specimens

- Fracture testing was performed on lab-cured beams formed in 2010 during CC6 construction
- FAA found strength losses in long-stored beams; cut cores and beams from the CC6 test items
- All specimens were kept in PSU wet curing chamber from arrival to testing:
 - 18 lab-cured cylinders and 18 lab-cured beams
(obtained June 2012; tested Aug-Sept 2012)
 - 10 field-cut cores and 10 field-cut beams
(obtained November 2012; tested January 2013)
 - 14 field-cut cores and 14 field-cut beams
(obtained March 2013; tested April and July 2013)


Fracture properties of concrete can be determined experimentally




Splitting Tensile Test



Three Point Bending Test



Crack opening



Displacement




Split Tensile Test




Split Tensile Results

<i>English</i>	Design MOR	28 Day MOR	PSU Split Tensile	
			Lab-Cured	Field-Core
	(psi)	(psi)	(psi)	(psi)
MRS1	500	662	413	377
MRS2	750	763	434	377
MRS3	1000	1007	471	481
<i>SI</i>	Design MOR	28 Day MOR	PSU Split Tensile	
			Lab-Cured	Field-Core
	(MPa)	(MPa)	(MPa)	(MPa)
MRS1	3.45	4.56	2.85	2.60
MRS2	5.17	5.26	2.99	2.60
MRS3	6.89	6.94	3.25	3.32

Closed-loop tests were used to determine the fracture energy



Three Point Bending Notched Specimens




Fracture Testing


3-point bending tests of notched beams

- Protocol from American Concrete Institute, 2007
- Very similar to that used in Europe and published by RILEM
- All data recorded at 4 Hz
- Typical test durations were 210 minutes
- Peak load reached in less than 5 minutes

Three Point Bending Schematic



Three Point Bending Test




Three Point Bending Test Controlled Variables

Closed-loop Control Used in Three Point Bending Test

	Control Variable	Rate	Ending point
Step 1	Load	0.5 kN/min	1 kN
Step 2	CMOD	0.01 mm/min	2 mm
Step 3	Displacement	0.1 mm/min	4 mm


Three Point Bending Test

Load vs. CMOD




Three Point Bending Test


Load vs. Plate Load Deflection



Stress vs. Crack Opening Curve




Fracture Energy



Average Fracture Energy Values


S/	Lab Cured		Field Sawn	
	Total Fracture Energy	Size Effect Fracture Energy	Total Fracture Energy	Size Effect Fracture Energy
	(N/m)	(N/m)	(N/m)	(N/m)
MRS1	129.7	51.3	88.9	36.0
MRS2	199.8	45.0	140.9	32.5
MRS3	210.3	44.0	134.1	56.2

Fracture Energy vs. Modulus of Rupture




* Error bars indicate standard errors

Split Tensile Strength versus Modulus of Rupture



* Error bars indicate standard errors

Elastic Modulus versus Modulus of Rupture



* Error bars indicate standard errors

Microscopic Examination

- Scanning Electron Microscopy (SEM)
 - Performed using FEI Quanta 200 Environmental SEM
 - Examination of microstructure
 - Possible cause(s) of strength loss with long-term storage
- Energy-dispersive X-ray Spectroscopy (EDS)
 - Examination of chemical composition of microscopic features


Macroscopic Examination



Prepared SEM Specimens




Prepared SEM Specimen




Prepared SEM Specimen




29S (MRS2) Field-Sawn Specimen




29S (MRS2) Field-Sawn Specimen



29S (MRS2) Field-Sawn Specimen




29N (MRS2) Lab-Cured Specimen




29N (MRS2) Lab-Cured Specimen




15N (MRS3) Field-Sawn Specimen




15N (MRS3) Field-Sawn Specimen




15N (MRS3) Field-Sawn Specimen




15N (MRS3) Lab-Cured Specimen




15N (MRS3) Lab-Cured Specimen




15N (MRS3) Lab-Cured Specimen




17N (MRS3) Field-Sawn Specimen




17N (MRS3) Field-Sawn Specimen




17N (MRS3) Lab-Cured Specimen




17N (MRS3) Lab-Cured Specimen




17N (MRS3) Lab-Cured Specimen




Aggregate Cracking Field-Sawn Ambient-Cured




Aggregate Cracking Field-Sawn Long-Cured



Ettringite Field Sawn Ambient-Cured



Ettringite Field Sawn Long-Cured



Summary of SEM Observations

Location	Slab	Type	Observations
MRS2	29N	Lab-cured (beam)	<ul style="list-style-type: none"> Ettringite formation Very few apparent pores
MRS2	29S	Field-sawn (beam)	<ul style="list-style-type: none"> Ettringite formation Significantly larger pore space distributed throughout the specimen
MRS3	15N	Lab-cured (beam)	<ul style="list-style-type: none"> Similar Si and Ca content in EDS analysis Voids of different size distributed throughout the specimen
MRS3	15N	Field-sawn (cylinder)	<ul style="list-style-type: none"> Ettringite formation More pores compared to lab-cured specimen
MRS3	17N	Lab-cured (cylinder)	<ul style="list-style-type: none"> Similar Si and Ca content in EDS analysis High amount of pores
MRS3	17N	Field-sawn (beam)	<ul style="list-style-type: none"> Similar Si and Ca content in EDS analysis Higher amount of pores compared to lab-cured specimen
MRS2	13N	Field-sawn (beam-ambient stored)	<ul style="list-style-type: none"> Ettringite Formation
MRS2	13N	Field-sawn (core-controlled curing)	<ul style="list-style-type: none"> More Ettringite formation compared to ambient-stored specimen Possible ASR in cracks based on EDS

SUMMARY

- Fracture & fatigue relationship is completely confounded with flexural strength, since one mix at each strength level tested
- Fracture energy results of lab-cured beams high given the NAPTF modulus of rupture results; possible effects of transport and different storage?
- No direct observations and little evidence of ASR; evidence of delayed ettringite formation

Acknowledgements



Federal Aviation
Administration

This research was conducted under a grant sponsored by the Federal Aviation Administration. The support of the NAPTF professional staff is greatly appreciated. Thank you also to Dr. Farshad Rajabipour for sharing his expertise with ASR and SEM.